AUDIOVOLT

WIFI GPS USB Music Movie DSP MIC Cam Touch AHD in CE FCC SRRC RoHS

Voor

NTG3.0-NTG6.0

Car mounted wireless intelligent connection terminal

Please note:

Dear user, after installing this system, for some models without AUX that require sound transmission through the original car Bluetooth, please first enter the original car system Bluetooth phone page and use the car's "Bluetooth phone" to actively search or wait for the Bluetooth device "DC_AUDIO_BT_****" of this system. After the Bluetooth of this system is successfully connected to the car's Bluetooth phone, enter the original car Bluetooth audio function, Press the corresponding button again to switch to the system page and start subsequent operations.

Disclaimer:

Apple、Iphone、Carplay

Apple, iPhone, Carplay, and the Carplay logo are registered trademarks and ownership of Apple Corporation

Android、Google Maps、Android auto　Waze　Google

Android, Google Maps, Android auto, and Waze are registered trademarks and ownership of Google Corporation

Baidu, Carlife, and the Carlife logo are registered trademarks and ownership of Baidu Company

Huawei, Huawei Hicar, and the Hicar logo are registered trademarks and ownership of Huawei Corporation


NO.1

/ Box parameters and warranty

Overall dimensions of products： 148mm　*91mm　*29mm	
Main chip model： T113-S	Power consumption current：1A（rated），3A（Max）
Dominant frequency： 1.2GHz	operating temperature：-40℃~+85℃
Memory： 256MB DDRIII SDRAM	Ambient humidity：≤98%（at45℃），65±5%（rated）
Storage space： 128MB NAND Flash	quiescent current：less than 3mA
Operating system： Linux	Storage temperature：-30~+85℃
Shutdown current：300mA（Clock is on）	Working height： 15000feet（4573 ）
running voltage： 9-16V，14.4V（rated）	Drop test： 30inches（76cm）


≤1.5A. when the USB charging current is > 3A, the host computer of the radio and receiver should start the circuit protection function to control the current below 1.5A to avoid burning the product.

NO.2 NTG3.0 / Schematic diagram of connection



NO.2-1 /Dip switch explained

NO.3 NTG3.5 / Schematic diagram of connection



NO.3-1 /Dip switch explained

NO.4 NTG3.0 /NTG3.5 /Operating instructions for steering wheel buttons



System volume increases

Call answering


System mute

System volume decreases

Press and hold for 2 seconds to enter the system page

End call

Voice awakening



Return to the previous level

Press and hold for 2 seconds to enter the system page

Short press back to the HOME page of the system


COMAND knob control system APP

Press to enter the APP function

Left dial and right dial control media up and down


Dialing up and down controls the cursor to move up and down

NO.5 NTG4.0 / Schematic diagram of connection



NO.5-1 /Dip switch explained

NO.6 NTG4.5 / Schematic diagram of connection



NO.6-1 /Dip switch explained



System volume increases

Voice awakening

Call answering

System mute

System volume decreases

Press and hold for 2 seconds to enter the system page

End call



Press and hold for 2 seconds to enter the system page

Short press back to the HOME page of the system

COMAND knob control system APP


Press to enter the APP function

Left dial and right dial control media up and down

Dialing up and down controls the cursor to move up and down

Return to the previous level

NO.8 NTG5.0 / Schematic diagram of connection



NO.8-1 /Dip switch explained



Voice awakening

Call answering

System volume increases

System volume decreases

Press and hold for 2 seconds to enter the system page

End call



Press and hold for 2 seconds to enter the system page

Short press back to the HOME page of the system

COMAND knob control system APP

Press to enter the APP function


Left dial and right dial control media up and down

Dialing up and down controls the cursor to move up and down

Mouse and touch operation

Switch between mouse and touch operation mode

NO.10 NTG5.5 / Schematic diagram of connection



NO.10-1 /Dip switch explained

NTG5.5(7")



NO.11 NTG5.5 /Operating instructions for steering wheel buttons



Voice awakening

Call answering

Press and hold for 2 seconds to enter the system page

End call



Press and hold for 2 seconds to enter the system page

Short press back to the HOME page of the system

COMAND knob control system APP

Press to enter the APP function


Left dial and right dial control media up and down


Dialing up and down controls the cursor to move up and down

Mouse and touch operation


Switch between mouse and touch operation mode

NO.12 NTG6.0 / Schematic diagram of connection





NO.12-1 /Dip switch explained





System volume increases


System volume decreases

Press and hold for 2 seconds to enter the system page

End call

Voice awakening

Call answering



Press and hold for 2 seconds to enter the system page

Short press back to the HOME page of the system

Mouse and touch operation

control media up and down

Switch between mouse and touch operation mode